



**Griform Innovations<sup>®</sup>, Inc.**  
**Shower Corner Shelf Installation**

Items you will need:

Denatured Alcohol  
Clean Lint Free Cloth  
100% Silicone Adhesive  
Hot Glue & Hot Glue Sticks

1. With denatured alcohol and clean white cloth, thoroughly clean the wall area where you will be installing the Shower Corner Shelf.
2. Mark on the wall where the shelf will be placed, and with the hot glue, adhere the glue blocks to the cleaned wall surface.
3. Once again with denatured alcohol and a clean white cloth thoroughly clean the wall area, and the edges of the shelf that receive the silicone.
4. Run a ¼" bead of silicone along the sides of the shelf, press lightly and evenly to make sure the silicone has good contact between the Shelf and the wall. Wait for the silicone to set. (Use silicone manufacturers suggested timelines for silicone curing.) Once the silicone has set, remove the blocks then once again clean around the outer rim of the caddy to make sure there is not any glue. Then run a thin bead of silicone around the outer rim of the Shelf to finish sealing to the shower wall.