



Griform Innovations[®], Inc.
Recessed Shower Caddy Installation

Items you will need: Cut-out Template (provided)

Plunge Router

½" router bit with 5/8" offset guide

Denatured Alcohol

Clean Lint Free Cloth

100% Silicone Adhesive

Hot Glue & Hot Glue Sticks

1. With denatured alcohol and clean white cloth, thoroughly clean the wall area where you will be installing the Shower Caddy.
2. Hot glue your template to the cleaned wall surface. Using the router bit and off set guide carefully cut the hole out in your wall. Make sure that the template is secure. Once the hole is cut remove the template.
3. Once again with denatured alcohol and a clean white cloth thoroughly clean the wall area around the hole, make sure that you remove any remaining hot glue.
4. Run a ¼" bead of silicone around the back side of the rim on the caddy. Install the caddy into the hole and press lightly and evenly around the rim to make sure the silicone has good contact between the back of the caddy frame and the wall. Tack the caddy to the shower wall with hot glue or tape. If using tape make sure that it is strong enough to hold caddy in place. Wait for the silicone to set. (Use silicone manufacturers suggested timelines for silicone curing.) Once the inside silicone has set, remove the hot glue or tape, then once again clean around the outer rim of the caddy to make sure there is not any glue or tape residue left. Then run a thin bead of silicone around the outer rim of the caddy to finish sealing the caddy to the shower wall.