



Griform Innovations[®], Inc. Threshold Installation

Items you will need: Denatured Alcohol
Clean Lint Free Cloth
100% Silicone Adhesive
Something to Use For Weight

1. Thoroughly vacuum or sweep the area where the threshold is to be placed.
2. With denatured alcohol and a clean white cloth thoroughly clean the area.
3. Lay a few ¼" beads of silicone adhesive on the back of the threshold. Place the threshold in place and firmly push down evenly along the threshold to ensure that the adhesive comes in contact with the floor.
4. Place weight bags or something heavy on the threshold until the silicone sets. Follow the recommended curing instructions on the tube of the silicone.